

FCL – Fume Cupboard Controller

FCL Version B03

*Power supply from a directly connected trafo or from the CAN-cable included 24VAC feed.

INTERLOCKING via EFK:
 RELAY/RELÄ set to 24VAC
230 VAC MY NOT BE CONNECTED DIRECTLY TO THE CONTROLLER
 EFK (Electrical interlocking contactor)

